U.S. DEPARTMENT OF HOMELAND SECURITY Federal Emergency Management Agency OMB Control No. 1660-0008 Expiration Date: 08/30/2028 National Flood Insurance Program

ELEVATION CERTIFICATE IMPORTANT: MUST FOLLOW THE INSTRUCTIONS ON INSTRUCTION PAGES 1-11

SECTION A – PROPERTY INFORMATION	FOR INSURANCE COMPANY USE
A1. Building Owner's Name: DAVID MORGAN FOR KIRK NAGY	Policy Number:
A2. Building Street Address (including Apt., Unit, Suite, and/or Bldg. No.) or P.O. Route and Box No.:	Company NAIC Number:
6705 EGRET POND LANE	
	ZIP Code: <u>32413</u>
A3. Property Description (e.g., Lot and Block Numbers or Legal Description) and/or Tax Parcel Number 197 RIVERCAMPS ON CROOKED CREEK UNIT 3. TAX ID (32611-814-000)	nber:
A4. Building Use (e.g., Residential, Non-Residential, Addition, Accessory, etc.): RESIDENTIAL	
A5. Latitude/Longitude: Lat. 30°17'26.76" N. Long. 85°49'21.29" W. Horiz. Datum:	NAD 1927 🗌 NAD 1983 🔀 WGS 84
A6. Attach at least two and when possible four clear color photographs (one for each side) of the be	uilding (see Form pages 7 and 8).
A7. Building Diagram Number: 6	
A8. For a building with a crawlspace or enclosure(s):	
a) Square footage of crawlspace or enclosure(s): 1,567.0 sq. ft.	
b) Is there at least one permanent flood opening on two different sides of each enclosed area?	⊠ Yes □ No □ N/A
c) Enter number of permanent flood openings in the crawispace or enclosure(s) within 1.0 foot Non-engineered flood openings:0 Engineered flood openings:12	
d) Total net open area of non-engineered flood openings in A8.c: 0.0 sq. in.	
e) Total rated area of engineered flood openings in A8.c (attach documentation – see Instruction	ons): 3000.0 sq. ft.
f) Sum of A8.d and A8.e rated area (if applicable – see Instructions): N/A sq. ft.	
A9. For a building with an attached garage:	
a) Square footage of attached garage: 0.0 sq. ft.	
b) Is there at least one permanent flood opening on two different sides of the attached garage?	P∐Yes ∐ No ⊠ N/A
c) Enter number of permanent flood openings in the attached garage within 1.0 foot above adjacent Non-engineered flood openings:0 Engineered flood openings:0	_
d) Total net open area of non-engineered flood openings in A9.c: 0.0 sq. in.	
e) Total rated area of engineered flood openings in A9.c (attach documentation – see Instruction	ons): 0.0 sq. ft.
f) Sum of A9.d and A9.e rated area (if applicable – see Instructions): N/A sq. ft.	···
SECTION B - FLOOD INSURANCE RATE MAP (FIRM) INFOR	RMATION
B1.a. NFIP Community Name: BAY COUNTY UNINCORPORATED AREA B1.b. NFIP Com	munity Identification Number: 120004
B2. County Name: BAY B3. State: FL B4. Map/Panel No.:	12005C0190 B5. Suffix: J
B6. FIRM Index Date: 12/24/2024 B7. FIRM Panel Effective/Revised Date: 12/24/20	24
B8. Flood Zone(s): AE B9. Base Flood Elevation(s) (BFE) (Zone AO, use B	Base Flood Depth): 12.0
B10. Indicate the source of the BFE data or Base Flood Depth entered in Item B9: FIS FIRM Community Determined Other:	
B11. Indicate elevation datum used for BFE in Item B9: ☐ NGVD 1929 ☒ NAVD 1988 ☐ Other	/Source:
B12. Is the building located in a Coastal Barrier Resources System (CBRS) area or Otherwise Prote Designation Date:	ected Area (OPA)? 🗌 Yes 🔀 No
B13. Is the building located seaward of the Limit of Moderate Wave Action (LiMWA)? Yes	No

Building Street Address (including Apt., Unit, Suite, and/or Bldg. No.) or P.O. Route and Box No.: 6705 EGRET POND LANE					R INSURANCE COMPANY USE			
		Policy Number:						
City: PANAMA CITY BEACH State: FL ZIP Code: 32413		Compa	ompany NAIC Number:					
SECTION C - BUILDING ELEVATION INFORMATION (SURVEY REQUIRED)								
C1. Building elevations are based on: Construction Drawings* Building Under A new Elevation Certificate will be required when construction of the building is com		n* 🛚	Fin	nished	Con	struction		
C2. Elevations – Zones A1–A30, AE, AH, AO, A (with BFE), VE, V1–V30, V (with BFE), AR, AR/A, AR/AE, AR/A1–A30, AR/AH, AR/AO, A99. Complete Items C2.a–h below according to the Building Diagram specified in Item A7. In Puerto Ricc only, enter meters. Benchmark Utilized: Q 773 2017 Vertical Datum: 88 DATUM								
Indicate elevation datum used for the elevations in items a) through h) below. □ NGVD 1929 ☑ NAVD 1988 □ Other:								
Datum used for building elevations must be the same as that used for the BFE. Conversion factor used? Yes No If Yes, describe the source of the conversion factor in the Section D Comments area. Check the measurement used:								
a) Top of bottom floor (including basement, crawlspace, or enclosure floor): 5.						meters		
b) Top of the next higher floor (see Instructions):	1	6.4	\boxtimes	feet		meters		
c) Bottom of the lowest horizontal structural member (see Instructions):		N/A		feet		meters		
d) Attached garage (top of slab):		N/A		feet		meters		
 e) Lowest elevation of Machinery and Equipment (M&E) servicing the building (describe type of M&E and location in Section D Comments area): 	1	13.0	\boxtimes	feet		meters		
f) Lowest Adjacent Grade (LAG) next to building: Natural Finished		5.2	\boxtimes	feet		meters		
g) Highest Adjacent Grade (HAG) next to building: Natural Finished		5.4	\boxtimes	feet		meters		
h) Finished LAG at lowest elevation of attached deck or stairs, including structural support:		5.4	\boxtimes	feet		meters		
SECTION D - SURVEYOR, ENGINEER, OR ARCHITEC	CT CERTIF	ICAT	ION					
This certification is to be signed and sealed by a land surveyor, engineer, or architect auth information. I certify that the information on this Certificate represents my best efforts to in false statement may be punishable by fine or imprisonment under 18 U.S. Code, Section	terpret the d							
Were latitude and longitude in Section A provided by a licensed land surveyor? X Yes	☐ No							
Check here if attachments and describe in the Comments area.								
Certifier's Name: ZANNIE THOMAS WHITE JR License Number: 6041								
Title: PRESIDENT								
Company Name: Z'S LAND SURVEYING & MAPPING, INC								
Address: PO BOX 401/1142 PERA ROAD		REG			*	PER		
	City: SAMSON State: AL ZIP Code: 36477							
Telephone: (850) 579-2315 Ext.: Email: zanniewhite@yahoo.com								
Signature: Zannie Thomas White Jr Digitally signed by Zannie Thomas White Jr Date: 2025.07.09 08:27:16 -05'00' Date: 07/09	/2025			Place	e Sea	al Here		
Copy all pages of this Elevation Certificate and all attachments for (1) community official, (2) i	nsurance ago	ent/cor	npar	ıy, and	l (3) l	ouilding owner.		
Comments (including source of conversion factor in C2; type of equipment and location points. LATITUDE AND LONGITUDE WERE DERIVED F.D.O.T. FRN NETWORK A.8 (b,c,d) THERE ARE 12 FREEDOM VENT FFV-1608, TOTAL COVERAGE A C2(e) AIR CONDITIONER SERVICING THE RESIDENCE D.SEE ATTACHED ICC-ES EVALUATION REPORT	GPS OBSE	RVA	TION	N		achments):		

Building Street Address (including Apt., Unit, Suite,	and/or Bld	ig. No.) d	or P.O. Route	and B	ox No	ı.:	FOR INSURA	NCE COMPANY USE
6705 EGRET POND LANE							Policy Number	:
City: PANAMA CITY BEACH	_ State:_	FL	_ ZIP Code:	3241	13		Company NAIC	Number:
SECTION E ⇒BUILDING FOR ZONE A								D)
For Zones AO, AR/AO, and A (without BFE), con intended to support a Letter of Map Change requenter meters.								
Building measurements are based on: Cons *A new Elevation Certificate will be required when		_	_	-		nstructio	n* Finished	d Construction
E1. Provide measurements (C.2.a in applicable measurement is above or below the natural language)				ing an	d che	ck the ap	propriate boxes	s to show whether the
 a) Top of bottom floor (including basement, crawlspace, or enclosure) is: 	,		□	feet		meters	above or	below the HAG.
 Top of bottom floor (including basement, crawlspace, or enclosure) is: 		- 51.		feet		meters	above or	below the LAG.
E2. For Building Diagrams 6–9 with permanent f next higher floor (C2.b in applicable	lood openi	ings pro	vided in Sect	on A I	ltems	8 and/or	9 (see pages 1-	-2 of Instructions), the
Building Diagram) of the building is:			🗆	feet		meters	above or	below the HAG.
E3. Attached garage (top of slab) is:			🗆	feet		meters	above or	☐ below the HAG.
E4. Top of platform of machinery and/or equipme servicing the building is:	ent			feet		meters	above or	below the HAG.
E5. Zone AO only: If no flood depth number is a floodplain management ordinance?								ne community's ormation in Section G.
SECTION F - PROPERTY OWNER	R (OR OV	VNER'	S AUTHORI	ZED	REPI	RESENT	TATIVE) CERT	TIFICATION
The property owner or owner's authorized repressign here. The statements in Sections A, B, and I						l E for Zo	ne A (without B	FE) or Zone AO must
☐ Check here if attachments and describe in the	e Commer	nts area.						
Property Owner or Owner's Authorized Represen	tative Nar	ne:						
Address:								
City:					Stat	:e:	ZIP Code:	
Telephone: Ext.:	Email:							
Signature:			Da	e:			_	
Comments:								

Building Street Address (including Apt., Unit, Suite, and/or Bldg. No.) or P.O. Route and Box No.:	FOR INSURANCE COMPANY USE						
6705 EGRET POND LANE	Policy Number:						
City: PANAMA CITY BEACH State: FL ZIP Code: 32413	Company NAIC Number:						
SECTION G - COMMUNITY INFORMATION (RECOMMENDED FOR COMMUNITY OFFICIAL COMPLETION)							
The local official who is authorized by law or ordinance to administer the community's floodplain ma Section A, B, C, E, G, or H of this Elevation Certificate. Complete the applicable item(s) and sign be							
G1. The information in Section C was taken from other documentation that has been signed engineer, or architect who is authorized by state law to certify elevation information. (Indelevation data in the Comments area below.)							
G2.a. A local official completed Section E for a building located in Zone A (without a BFE), Zone E5 is completed for a building located in Zone AO.	ne AO, or Zone AR/AO, or when item						
G2.b. A local official completed Section H for insurance purposes.							
G3.	e information in Sections A, B, E and H.						
G4.	ment purposes.						
G5. Permit Number: PRSF202408308 G6. Date Permit Issued: 12-04-7	24						
G7. Date Certificate of Compliance/Occupancy Issued:							
G8. This permit has been issued for: New Construction Substantial Improvement							
G9.a. Elevation of as-built lowest floor (including basement) of the building:	meters Datum:						
G9.b. Elevation of bottom of as-built lowest horizontal structural member:	meters Datum:						
G10.a. BFE (or depth in Zone AO) of flooding at the building site:	meters Datum:						
G10.b. Community's minimum elevation (or depth in Zone AO) requirement for the lowest floor or lowest horizontal structural member:	meters Datum:						
G11. Variance issued? Yes No If yes, attach documentation and describe in the Con	nments area.						
The local official who provides information in Section G must sign here. I have completed the information to the best of my knowledge. If applicable, I have also provided specific corrections in the Co	nation in Section G and certify that it is						
Local Official's Name: Title: Plans	42						
NFIP Community Name:							
Telephone: Ext.: Email:							
Address:							
	ZIP Code:						
Signature: Date: 7-9-2	5						
Comments (including type of equipment and location, per C2.e; description of any attachments; and Sections A, B, D, E, or H):	corrections to specific information in						
B13 Property 15 seaward of Limba							

6705 EGRET POND LANE Policy Number:	JSE
City: PANAMA CITY BEACH State: FL ZIP Code: 32413 Company NAIC Number:	
SECTION H.— BUILDING'S FIRST FLOOR HEIGHT INFORMATION FOR ALL ZONES (SURVEY NOT REQUIRED) (FOR INSURANCE PURPOSES ONLY)	
The property owner, owner's authorized representative, or local floodplain management official may complete Section H for all flood zo to determine the building's first floor height for insurance purposes. Sections A, B, and I must also be completed. Enter heights to the nearest tenth of a foot (nearest tenth of a meter in Puerto Rico). Reference the Foundation Type Diagrams (at the end of Section I Instructions) and the appropriate Building Diagrams (at the end of Section I Instructions) to complete this section.	
H1. Provide the height of the top of the floor (as indicated in Foundation Type Diagrams) above the Lowest Adjacent Grade (LAG):	
a) For Building Diagrams 1A, 1B, 3, and 5–8. Top of bottom	
b) For Building Diagrams 2A, 2B, 4, and 6–9. Top of next	
H2. Is all Machinery and Equipment servicing the building (as listed in Item H2 instructions) elevated to or above the floor indicated by H2 arrow (shown in the Foundation Type Diagrams at end of Section H instructions) for the appropriate Building Diagram? [Yes No	the
SECTION : - PROPERTY OWNER (OR OWNER'S AUTHORIZED REPRESENTATIVE) CERTIFICATION	소 등 등
The property owner or owner's authorized representative who completes Sections A, B, and H must sign here. The statements in Section A, B, and H are correct to the best of my knowledge. Note: If the local floodplain management official completed Section H, they should	ions d
indicate in Item G2.b and sign Section G.	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area.	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: State: ZIP Code:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: State: ZIP Code: Telephone: Ext.: Email:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	
indicate in Item G2.b and sign Section G. Check here if attachments are provided (including required photos) and describe each attachment in the Comments area. Property Owner or Owner's Authorized Representative Name: Address: City: Telephone: Ext.: Email: Date: Date:	

IMPORTANT: MUST FOLLOW THE INSTRUCTIONS ON INSTRUCTION PAGES 1-11 BUILDING PHOTOGRAPHS

See Instructions for Item A6.

Building Street Address (including Apt., Unit	, Suite, and/or Blo	lg. No.)	or P.O. Route and Box No.:	FOR INSURANCE COMPANY US		
6705 EGRET POND LANE				Policy Number:		
City: PANAMA CITY BEACH	State: _	FL	ZIP Code: 32413	Company NAIC Number:		

Instructions: Insert below at least two and when possible four photographs showing each side of the building (for example, may only be able to take front and back pictures of townhouses/rowhouses). Identify all photographs with the date taken and "Front View," "Rear View," "Right Side View," or "Left Side View." Photographs must show the foundation. When flood openings are present, include at least one close-up photograph of representative flood openings or vents, as indicated in Sections A8 and A9.




Photo One

Photo One Caption: STREET VIEW 07/07/2025

Clear Photo One



Photo Two

Photo Two Caption: RIGHT SIDE VIEW 07/07/2025

Clear Photo Two

IMPORTANT: MUST FOLLOW THE INSTRUCTIONS ON INSTRUCTION PAGES 1-11 BUILDING PHOTOGRAPHS

Continuation Page

Building Street Address (including Apt., Unit, S	FOR INSURANCE COMPANY USE				
6705 EGRET POND LANE					Policy Number:
City: PANAMA CITY BEACH	State:_	FL	_ ZIP Code:	32413	Company NAIC Number:

Insert the third and fourth photographs below. Identify all photographs with the date taken and "Front View," "Rear View," "Right Side View," or "Left Side View." When flood openings are present, include at least one close-up photograph of representative flood openings or vents, as indicated in Sections A8 and A9.



Photo Three

Photo Three Caption: REAR VIEW 07/07/2025

Clear Photo Three



Photo Four

Photo Four Caption: LEFT SIDE VIEW WITH AC & VENTS 07/07/2025

Clear Photo Four



ICC-ES Evaluation Report

ESR-4332

Reissued March 2020

This report is subject to renewal March 2022.

www.icc-es.org | (800) 423-6587 | (562) 699-0543

A Subsidiary of the International Code Council®

DIVISION: 08 00 00—OPENINGS

Section: 08 95 43-Vents / Foundation Flood Vents

REPORT HOLDER:

SMART PRODUCT INNOVATIONS, INC.

EVALUATION SUBJECT:

FREEDOM FLOOD VENT™ AUTOMATIC FOUNDATION FLOOD VENT: MODEL FFV-1608

1.0 EVALUATION SCOPE

Compliance with the following codes:

- 2018, 2015, 2012, 2009 and 2006 International Building Code[®] (IBC)
- 2018, 2015, 2012, 2009 and 2006 International Residential Code® (IRC)

Properties evaluated:

- Physical operation
- Water flow
- Weathering

2.0 USES

The model FFV-1608 Freedom Flood Vent™ is used to equalize hydrostatic pressure on walls of enclosures subject to rising or falling floodwaters. With the cover removed, the model FFV-1608 also provides natural air ventilation.

3.0 DESCRIPTION

3.1 General:

The model FFV-1608 Freedom Flood Vent™ is an engineered mechanically operated in-wall flood vent (FV) that automatically allows floodwater to enter an enclosed area and exit. The FV is comprised of a polycarbonate frame with mounting flange and a polycarbonate horizontally pivoting door. When subjected to rising water, the model FFV-1608 Freedom Flood Vent™ door is activated and pivots to allow water and debris to flow in either direction to equalize hydrostatic pressure from one side of the enclosure to the other. The FV features a removable polycarbonate cover. The FV door will activate and pivot when subjected to rising water with or without the polycarbonate cover installed.

3.2 Engineered Opening:

The FV complies with the design principle noted in Section 2.7.2.2 and Section 2.7.3 of ASCE/ SEI 24-14 (2018 and 2015 IBC and IRC) [Section 2.6.2.2 of ASCE/ SEI 24-05 (2012, 2009, 2006 IBC and IRC)] for a maximum rate of rise and fall of 5.0 feet per hour (0.423 mm/s). In order to comply with the engineered opening requirement of ASCE/ SEI 24, Freedom Flood Vent™ FVs must be installed in accordance with Section 4.0 below. See Table 1 for vent size and maximum allowable area coverage for a single vent.

4.0 DESIGN AND INSTALLATION

The model FFV-1608 Freedom Flood Vent™ is designed to be installed into walls or overhead doors of existing or new construction. Installation of the vent must be in accordance with the manufacturer's instructions, the applicable code, and this report. In order to comply with the engineered opening design principle noted in Sections 2.7.2.2 and 2.7.3 of ASCE/ SEI 24-14 (2018 and 2015 IBC and IRC) [Section 2.6.2.2 of ASCE/ SEI 24-05 (2012, 2009, 2006 IBC and IRC)], the Freedom Flood Vent™ must be installed as follows:

- With a minimum of two openings on different sides of each enclosed area.
- With a minimum of one FV for every 250 square feet (23.2 m²) of enclosed area.
- Below the base flood elevation.
- With the bottom of the vent located a maximum of 12 inches (305.4 mm) above the higher of the final interior grade or floor and the finished exterior grade immediately under each opening.

5.0 CONDITIONS OF USE

The Freedom Flood Vent™ described in this report complies with, or is a suitable alternative to what is specified in, those codes listed in Section 1.0 of this report, subject to the following conditions:

- 5.1 The model FFV-1608 Freedom Flood Vent™ unit must be installed in accordance with this report, the applicable code and the manufacturer's published installation instructions. In the event of a conflict, the instructions in this report shall govern.
- 5.2 The model FFV-1608 Freedom Flood Vent™ unit must not be used in place of "breakaway walls" in coastal high hazard areas, but are permitted for use in conjunction with breakaway walls in other areas.



5.3 Use of the Freedom Flood Vent as under-floor space ventilation is outside the scope of this report.

6.0 EVIDENCE SUBMITTED

Data in accordance with the ICC-ES Acceptance Criteria for Mechanically Operated Flood Vents (AC364), dated August 2015 (editorially revised October 2017).

7.0 IDENTIFICATION

7.1 The Freedom Flood Vent™ model recognized in this report must be identified by a label bearing the manufacturer's name (Smart Product Innovations, Inc.) and the evaluation report number (ESR-4332.).

7.2 The report holder's contact information is the following:

SMART PRODUCT INNOVATIONS, INC. 430 ANDBRO DRIVE, UNIT 1 PITMAN, NEW JERSEY 08071 (800) 507-1527 www.freedomfloodvent.com

info@freedomfloodvent.com

TABLE 1—FREEDOM FLOOD VENT™

MODEL NAME	MODEL NUMBER	MODEL SIZE	COVERAGE (sq. ft.)
Freedom Flood Vent™	FFV-1608	15 ³ / ₄ " X 8 ¹ / ₁₆ "	250

For SI: 1 inch = 25.4 mm




FIGURE 1—MODEL FFV-1608 FREEDOM FLOOD VENT™: SHOWN WITH COVER REMOVED



FIGURE 2—MODEL FFV-1608 FREEDOM FLOOD VENT™: SHOWN WITH FLOOD DOOR PIVOTED OPEN



ICC-ES Evaluation Report

ESR-4332 CBC and CRC Supplement

Reissued March 2020

This report is subject to renewal March 2022.

www.icc-es.org | (800) 423-6587 | (562) 699-0543

A Subsidiary of the International Code Council®

DIVISION: 08 00 00—OPENINGS

Section: 08 95 43-Vents / Foundation Flood Vents

REPORT HOLDER:

SMART PRODUCT INNOVATIONS, INC.

EVALUATION SUBJECT:

FREEDOM FLOOD VENT™ AUTOMATIC FOUNDATION FLOOD VENT: MODEL FFV-1608

1.0 REPORT PURPOSE AND SCOPE

Purpose:

The purpose of this evaluation report supplement is to indicate that the Freedom Flood Vent™ Automatic Foundation Flood Vent: Model FFV-1608, recognized in ICC-ES master evaluation report ESR-4332, has also been evaluated for compliance with codes noted below.

Applicable code edition(s):

- 2016 California Building Code (CBC)
- 2016 California Residential Code (CRC)

2.0 CONCLUSIONS

2.1 CBC:

The Freedom Flood Vent™ Automatic Foundation Flood Vent: Model FFV-1608, described in Sections 2.0 through 7.0 of the master evaluation report ESR-4332, complies with CBC Chapters 12, 16 and 16A, provided the design and installation are in accordance with the 2015 *International Building Code*® (2015 IBC) provisions noted in the master report and the additional requirements of 12, 16, and 16A, as applicable.

The product recognized in this supplement has not been evaluated under CBC Chapter 7A for use in the exterior design and construction of new buildings located in any Fire Hazard Severity Zone within State Responsibility Areas or any Wildland-Urban Interface Fire Area.

2.2 CRC:

The Freedom Flood Vent™ Automatic Foundation Flood Vent: Model FFV-1608, described in Sections 2.0 through 7.0 of the master evaluation report ESR-4332, complies with the 2016 CRC, provided the design and installation are in accordance with the 2015 *International Residential Code*® (2015 IRC) provisions noted in the master report.

The product recognized in this supplement has not been evaluated under 2016 CRC Chapter R337, for use in the exterior design and construction of new buildings located in any Fire Hazard Severity Zone within State Responsibility Areas or any Wildland-Urban Interface Fire Area.

The product recognized in this supplement has not been evaluated for compliance with the *International Wildland–Urban Interface Code*®.

This supplement expires concurrently with the evaluation report, reissued March 2020.





ICC-ES Evaluation Report

ESR-4332 FBC Supplement

Reissued March 2020

This report is subject to renewal March 2022.

www.icc-es.org | (800) 423-6587 | (562) 699-0543

A Subsidiary of the International Code Council®

DIVISION: 08 00 00—OPENINGS

Section: 08 95 43—Vents / Foundation Flood Vents

REPORT HOLDER:

SMART PRODUCT INNOVATIONS, INC.

EVALUATION SUBJECT:

FREEDOM FLOOD VENT™ AUTOMATIC FOUNDATION FLOOD VENT: MODEL FFV-1608

1.0 REPORT PURPOSE AND SCOPE

Purpose:

The purpose of this evaluation report supplement is to indicate that Freedom Flood Vent™ Automatic Foundation Flood Vent: Model FFV-1608, recognized in ICC-ES master evaluation report ESR-4332, has also been evaluated for compliance with the codes noted below.

Applicable code editions:

- 2017 Florida Building Code—Building
- 2017 Florida Building Code—Residential

2.0 CONCLUSIONS

The Freedom Flood Vent™ Automatic Foundation Flood Vent: Model FFV-1608, described in Sections 2.0 through 7.0 of the master evaluation report ESR-4332, complies with the Florida Building Code-Building and the Florida Building Code-Residential, provided the design and installation are in accordance with the International Building Code® (IBC) provisions noted in the master report.

Use of the Freedom Flood Vent™ Automatic Foundation Flood Vent: Model FFV-1608 has also been found to be in compliance with the High-Velocity Hurricane Zone provisions of the Florida Building Code—Building and the Florida Building Code—Residential.

For products falling under Florida Rule 9N-3, verification that the report holder's quality assurance program is audited by a quality assurance entity approved by the Florida Building Commission for the type of inspections being conducted is the responsibility of an approved validation entity (or the code official, when the report holder does not possess an approval by the Commission).

This supplement expires concurrently with the evaluation report, reissued March 2020.

